

RAPID

PROGRAMMING HANDSET

The programming handset is used to configure all system devices. The handset has a simple to use text based menu and keypad. The programming handset also has user menus which allow IDs and timing information to be read back from system devices.



ORDER CODE	DESCRIPTION
EBS-LCDHS	Programming handset

RAPID

USER HANDSET

The handset allows the user to override the system detectors. There are two types available: the 8 button handset (part number UHS) can be used to adjust lux settings and override the detector ON/OFF. The 3 button (part number UHS3) is used to override the system detectors ON/OFF.



ORDER CODE	DESCRIPTION
UHS	User handset override on/off, lux up, lux down
UHS3	User handset on/off

